


Rear Toe Arms Kit Installation Instructions SPL RTA FRS



www.splparts.com

Questions? 512-691-9002

tech@splparts.com



Introduction

Thank you for your purchase of this SPL Parts performance suspension product. These products are intended to provide experienced chassis tuners enhanced performance and flexibility in dialing-in your suspension settings. Please read these instructions fully before attempting installation. If you have further questions contact us at: tech@splparts.com. The SPL team is here to help.

A Few Words About Product Safety:

Within these Installation Instructions important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words mean:

AWARNING A hazardous situation which, if not avoided, could result in death or serious injury. You CAN be KILLED or Seriously HURT if you do not follow instructions.

A CAUTION A hazardous situation which, if not avoided, could result in minor or moderate injury. You CAN be moderately HURT and may suffer property damage if you do not follow instructions.

NOTICE Careful attention is required to this instruction or operation but does generally not relate to personal injury. Damage to you SPL product or other property may result if you do not follow instructions.



www.splparts.com

Questions? 512-691-9002

tech@splparts.com



WARNING

Installation of your SPL components and enhanced suspension performance may result in your vehicle handling differently than as factory equipped. Your choice of tire and wheel combinations, camber and toe-in settings may reduce braking performance and/or result in excessive wear or damage to SPL and OEM components during competition, track day or high-stress on road use. Contacts with other vehicles, pot holes or uneven road surfaces may result in overload stresses to fasteners, heim joints and other components initiating either immediate or accelerated failures. *To reduce risks of accident and serious injury always:*

- Routinely inspect OEM suspension and steering components, braking system and SPL components including control arms, fasteners and heim joints for indications of overload stress, bending or physical damage (however, slight). Remove fasteners and heim joints as necessary to reveal potential damage within sleeves and joints. Best practices for competition and track includes inspection before and after each session, capturing driver input regarding any impacts, unusual vibration, or suspension feedback.
- Immediately remove and replace any OEM or SPL component or fastener with indicated or suspected damage (including bending or damaged threads).
- Do Not modify or substitute SPL components, over torque fasteners through use of impact or air tools or configure suspension settings outside of those recommended by OEM or established through owner testing of vehicle.
- Use of oversize tire/wheel combinations may increase stopping distances, modify ride height, roll centers and/or compromise performance of vehicle stability control and other systems.
- Certain states regulate on highway suspension modifications. Vehicle owner and driver responsible for compliance with all equipment laws and regulations.
- All Occupants Buckle UP, USE Supplemental Restraints, and required SCCA or other club crash protection.

AWARNING SPL recommends professional installation of these components by technicians having access to vehicle lift, safety glasses/personal protective gear and experience with OEM maintenance techniques, recommendations, safety messaging, torque & other specifications.

AWARNING Cancer and Reproductive Harm – www.P65Warnings.gov.

www.splparts.com

Questions? 512-691-9002



Safety Requirements:

- **AWARNING** Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- **ACAUTION** Always use properly rated jack stands or an automotive lift when working under your Vehicle.

Tools Required:

- Ratchet
- Ratchet Extension
- Sockets
- Wrenches

Procedure:

- 1. **ACAUTION** Raise and secure the rear end of the car and remove the rear wheels.
- 2. If you are reusing the OEM eccentric nut and bolt, mark the location with a marker allowing you to reinstall in the same exact location.
- 3. Remove the stock toe arm eccentric nut and bolt (location 1) with a 17mm wrench and socket.




www.splparts.com

Questions? 512-691-9002


tech@splparts.com



- 4. Remove the cotter pin and nut attaching the stock toe arm to the knuckle (location 2) with a 19mm and 22mm socket or wrench. Using a pickle fork, separate the arm from the spindle. If you don't have a pickle fork, thread the nut partially onto the OEM stud and knock it out with a hammer, being careful not to damage the threads.
- 5. Measure from the center of bolt hole 1 to bolt hole 2 on the OEM arm and set your new SPL Parts Arm to that length. Final adjustment can be made after the arm is installed on the car.
- 6. Attach the SPL Parts Arm to the subframe (location 1) with the eccentric nut and bolt using a 19mm and 22mm wrench and socket, and adjust the eccentric to the same marked location from Step 2. **NOTICE** if using optional Eccentric Lockout kit, insert the square lockout washers in the subframe slots and use the 19mm socket and the 18mm wrench.
- 7. Attach the SPL Parts Arm to the spindle with the supplied 19mm bolt (location 2) as shown.**NOTICE** the taper adapter should go in the tapered portion of the spindle.



- 8. Torque all bolts to spec (59 ft-lbs) and make final adjustments.
- 9. Tighten the Aluminum Clamps (5) with the Blue Titanium Socket Head Cap Screws (8) using a 3/16 allen wrench. Torque to 150 in-lbs. This is generally accomplished with a normal 3/16" allen key, but make sure that the allen key is fully seated. The goal is to make sure the linkage cannot be rotated without excessive force.
- 10. **NOTICE** Following installation have the car professionally aligned, as replicating the original settings is nearly impossible. It may be necessary to adjust the toe in order to drive the car to an alignment shop if you either added or subtracted camber. Take these instructions with you to ensure that the parts are adjusted correctly.
- 11. **AWARNING** Check all torques after the first 100 and 500 miles of driving, or after your first two sessions at the track if it is a track car, to make sure that nothing has loosened up due to vibrations. Maintain a full copy of SPL Instructions and product safety messaging with your vehicle maintenance records.





Adjusting the Length of the Links for Alignment

Loosen the clamps on both ends of the dogbone. Turn the dogbone to thread in/thread out the rod ends. Once the assembly is the correct length, tighten the clamps by torquing the socket head cap screws to 150 IN-LBS maximum or until the assembly cannot be rotated easily.

ACAUTION Note that the thread engagement exposed on the rod end should not exceed .625" as shown in the photo.



www.splparts.com

Questions? 512-691-9002



SPL™ LIMITED WARRANTY1

What is Covered? Subject to the terms, exclusions and limitations herein, SPL Parts, Inc. ("SPL") exclusively warrants to the owner of the vehicle SPL components are initially installed on, SPL will, according to terms herein, repair or replace defects in SPL materials or workmanship that upon SPL's inspection are determined to exist as of the date of sale to the initial end user/customer (hereafter "Customer").

The term of this Limited Warranty shall be twenty-four months from SPL delivery to first end user/Customer. •

What is Not Covered?: Your SPL Limited Warranty does not cover: (1) defect in a SPL component causing or contributing to damage to the motorized chassis, body, emissions, belting/airbags, electrical system or other vehicle system or component separately warranted or supplied by a manufacturer other than SPL, (2) SPL components used in competition or other events which may involve unforeseen vehicle components, suspension set ups and contact between vehicles and obstacles, (3) damage to SPL components or your vehicle from additions, alterations, or other products or components not supplied by SPL, (4) damage or degradation of performance from failure to adequately inspect, maintain, adjust or service as recommended or required, damage resulting from improper suspension set-up, loading, accident, collision, vandalism, abuse, misuse, neglect, fire, flood, normal wear, (5) damage caused or related to use of SPL control arms or other parts as a tie-down for dyno testing or transport (6) labor, consequential, incidental, punitive or other damages or costs, including those incurred in removing or delivering your SPL component to SPL for inspection, repair or replacement.

Obtaining Warranty & Customer Service: For questions or claims contact: SPL Warranty, 30307 Ranch Road 12, Unit 100, Dripping Springs, Texas 78620; Tech@splparts.com. Please have proof of purchase available.

Remedy Limited to Repair/Replacement by SPL. Limited time for Filing Warranty Claims. BINDING, SINGLE CLAIM ARBITRATION-Venue: Upon Customer's removal and delivery to SPL, SPL inspection and SPL determination of a covered defect, the exclusive remedy provided hereunder shall at SPL's option be repair or replacement of the defective SPL component. Written notice of any claim for breach/damages related to this Limited Warranty must be provided SPL within 20 days of customer notice or concern with a defect and in all instances within 30 days of the date your Limited Warranty expires (i.e. not later than twenty-five months from delivery). For separate, valuable consideration received; all claims arising from or related to purchase or use of SPL components shall exclusively be maintained as a separate action by each Customer with jurisdiction, venue and determination applying Texas state law (without reference to treaties or conflict of law provisions) through binding arbitration before a neutral selected by Customer from the JAMS® panel closest to Austin, Texas. To the extent permitted by law, each party shall bear its own costs and fees

Other Exclusions –Limitation of Damages - Your Rights Under State Law. In consideration of the purchase price negotiated, SPL shall not be liable for: costs incurred by Customer removing, transporting or presenting components to SPL for repair or replacement under this Limited Warranty (expedited or other shipping is Customer's responsibility), any time loss, rental costs, towing or for any incidental, consequential, punitive or other damages Customer may incur arising or in any way related to Customer's negotiation, purchase and use of SPL components. Your exclusive remedy hereunder is repair or replacement as described above. By claiming the benefits of this Limited Warranty Customer agrees: (a.) your sole and exclusive remedy in any proceeding for breach of this express Limited Warranty is money damages in an amount equal to the lesser of the purchase price of the covered SPL part or the reasonable cost for material and labor necessary to repair or replace SPL components that Customer proves at arbitration should have been done hereunder but were not; (b.) your sole and exclusive remedy in a proceeding for breach of any applicable implied warranty is money damages in an amount equal to the lesser of the purchase price of the covered SPL part or the amount Customer proves at arbitration equal to the reasonable cost for material and labor necessary to correct the defect(s) in SPL components upon which the finding of breach of implied warranty is based. This Limited Warranty of repair or replacement shall not be construed as a representation or warranty of future performance. The duration of any implied warranty shall be limited to the term of express Limited Warranty provided above. By making a claim under this Limited Warranty you acknowledge receipt of these terms and agreement to be bound thereby.

No employee or other agent of SPL is authorized to amend or waive this written Limited Warranty or make additional representations or warranties regarding any SPL features, performance, workmanship or materials. This Limited Warranty shall be construed according to Texas Law without reference to treaties or conflict of law principles.

This Limited Warranty gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you. All other warranties are hereby disclaimed, except to the extent prohibited by applicable law.

¹ © Copyright licensed to SPL, Parts, Inc.

www.splparts.com

Questions? 512-691-9002