



## **FRONT BUMPER INSTALLATION INSTRUCTIONS** **1999-2005, Ford Excursion**

### **Please read before beginning**

- *Stainless steel hardware may bind together when tightening—It is recommended that you apply an anti-seize assembly lubricant to the threads of each bolt before assembly*
- *This installation requires two people*

### **Required tools**

- Standard wrench set
- Leveling tool



### **Included hardware**

### **Quantity**

- |  |    |
|--|----|
| • Mounting hardware                                      |    |
| ○ 70036 - 1/2-13 x 1 1/2" Hex head bolt grade 8          | 8  |
| ○ 70034 - 1/2-13 Nuts, stainless steel with nylon insert | 8  |
| ○ 70035 - 1/2 Washer                                     | 16 |
| • 400511- Winch, Fairlead Cover                          | 1  |
| ○ 70008- 1/4-20 Nylock Nuts SS                           | 2  |
| ○ 70039- 1/4 x 7/8 Fender Washer SS                      | 4  |
| ○ 70060- 1/4-20 x 1" Button Head Bolt SS                 | 2  |
| • 400503.4 - Keys, tool box lock set                     | 1  |

### **Assembly instructions**

1. Remove Stock Bumper
2. Hold Aluminess bumper up in position and put the 1/2" bolt through the bumper and frame
3. Next, put one bolt on each side (each bolt should have a washer on both the head and the nut sides)
4. The hole on the bumper that is furthest away from the frame is the easiest one to start with
5. Hand tighten the nut down so the bumper can be rested on the bolt
6. Insert the other four bolts that go from inside the toolbox to the frame
7. Tighten the nuts down so that the bumper is held up but can still be moved
8. Check that the bumper is level and aligned with the center of the truck
9. Tighten down all of the fasteners, and check again after driving 100 miles to make sure everything is still secure