

# POWERFLEX®

## PART NUMBER

# PFF5-101MS

## DESCRIPTION

### FRONT WISHBONE REAR BUSH SUPPORT KIT

## INSTALLATION GUIDE

### Contents (parts per pack):

- 2 x Stainless Steel Spacers
- 2 x Shakeproof washers
- 2 x M14 Mounting Bolts
- 2 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

**PFF5-101MS is to provide additional support to PFF5-101**



### Fitting Instructions:

1. The centre of the original front wishbone should be tapped using a M14 tap.
2. Fit POWERFLEX PFF5-101 to the front wishbone.
3. Fit the spacer in the centre of the bush on the end pin of the arm.
4. Fit the washer over the end of the bush and secure using the M14 bolt and shakeproof washer provided.

**Tip: Use Loctite thread lock liquid on the bolt to help secure the assembly.**



Figure 1