

Bullet Nose Wheel Stud Kit**034 MOTOR SPORT**

034Motorsport's new black zinc coated wheel stud kits are made of Grade 10.9 Chromoly Steel and the bullet nose feature allows for quick, self-aligning wheel installation. Designed with large shoulders to provide extra strength and to properly fit VAG brake rotor hats. These will work with wheel spacers up to 10mm thick.

Installation Spiciness Rating: MILD

Installation of your 034Motorsport Bullet Nose Wheel Stud Kit is a straightforward process that will take approximately 1 hour to complete.

Supplied Parts:

- (1x) 034Motorsport Bullet Nose Wheel Stud Kit

Tools Needed:

- (2x) 19mm Wrenches

Supplies Recommended:

- Blue Loc-Tite

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

customerservice@034motorsport.com

About This Guide

This Install Guide documents the installation process on an 8Y Audi S3. There may be minor differences depending on specific vehicle, market, options, etc.

Install Steps

Step 1

Lift the car.



Step 2

Remove the wheels.



Step 3 (Optional)

Apply a small drop of blue Loc-tite to the threads.



Step 4

Install the wheel stud by hand until it bottoms out.



Step 5

Thread a lug nut onto the wheel stud.



Step 6

Thread a second nut onto the stud.



Step 7

Use (2x) 19mm wrenches to lock the lug nuts in place.



Step 8

Using a 19mm wrench, tighten the whole assembly from the outermost lug nut.



Step 9

Use (2x) 19mm wrenches to break the lug nuts apart.



Step 10

Remove the lug nuts.



Step 11

Repeat the process until all studs have been installed.

Step 12

Put the wheels back on.



Step 13

Install the lug nuts and you are done!

