



Audi Q7 Roof rack install

We currently don't have photos but will be updating soon.

1. Remove headliner.
2. Unbolt OEM roof rails. They are held on in 5 places on each side with 10mm nuts. After unbolting you can remove the OEM rails.
3. Install the 10 supplied brackets that mount to the side rails onto the roof first. Do not fully tighten them. They will be mounted with the M6 bolts with the built in sealed washer. the supplied rubber seal goes between the roof and the brackets. 1 seal per bracket.
4. Use the oversized washer and locking nut to attach on the inside of the car the the help of someone holding the bolt on the outside.
5. Now install the side rails. With everything bolted on the 10 brackets on both sides you can proceed to install the cross bars.
6. install all the cross bars hand tight spaced out according to how you like the orientation.
7. Once all the cross bars are installed you can tighten all the cross bars fully.
8. Now tighten the brackets that attach the side rails to the roof brackets.
9. lastly now bolt the M6 nuts / bolts that go thru the roof. They can be tightened up to 15ft lbs.
10. Reinstall headliner.

***IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT
PLEASE CONTACT US!***