



Gwagen W463 rear brake line bracket install

1. remove two 13mm bolts on factory brake line bracket.
2. install supplied brake line bracket (follow angle of bracket according to photos below)
3. install original bracket on top mounting holes of new bracket
4. install supplied hardware.

<https://shop.eurowise.com/ProductDetails.asp?ProductCode=W463BKLB>





***IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT
PLEASE CONTACT US!***