



ADVENTURE  
FURTHER®

# #7336 KC® DITCH MOUNT BRACKETS 2021+ TOYOTA TUNDRA

## INSTALLATION INSTRUCTIONS

**IMPORTANT:** Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.

### KIT INCLUDES:

- (1) DRIVER SIDE DITCH BRACKET
- (1) PASSENGER SIDE DITCH BRACKET

### TOOLS REQUIRED:

- 1. METRIC SOCKET / WRENCH SET
- 2. PAINTER'S TAPE
- 3. MARKER



## STEP BY STEP INSTALLATION INSTRUCTIONS

**\*\*ONLY INSTALL ONE SIDE AT A TIME TO ENSURE PROPER HOOD ALIGNMENT\*\***

1. Place some Painter's Tape along the factory hinge & hood; and with the marker, make a conspicuous mark to show the alignment.
2. Begin the installation by removing one of the hood hinge bolts (**DO NOT REMOVE BOTH BOLTS SIMULTANEOUSLY**). Once the bolt is removed, align the bracket to the hole and tighten the Ditch Mount Bracket until snug.
3. Pro Tip: Give yourself enough room to remove the other bolt.
4. Remove the remaining hood hinge bolt and rotate the Ditch Mount Bracket until hole alignment, then reinstall hood hinge bolt.
5. Check the original alignment of hood markings. Adjust hood alignment if necessary before final tightening of hood hinge bolts. **TORQUE: 13-NM (9 ft-lbs)**
6. Repeat Steps 1-4 on remaining Ditch Mount Bracket