Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105 North Las Vegas, NV 89081 TEL: 702-399-1423 FAX: 702-399-1431 8am-5pm Pacific Time Monday through Friday

Website Address http://www.dynojet.com

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.




WARNING

NO SMOKING! NO OPEN FLAME! WHILE INSTALLING YOUR DYNOJET KIT

1199.002 U.S Models Only

2004 & 2006 Honda CB600F (599) Stage 1

For mildly tuned machines using the stock airbox, with stock or K&N filter. May also be used with a good aftermarket exhaust system.



This graph shows a typical gain with a Dynojet jet kit.

Parts List		
4	Main Jets	DJ086
4	Main Jets	DJ088
4	Main Jets	DJ090
4	Main Jets	DJ092
4	Main Jets	DJ094
4	Main Jets	DJ096
4	Main Jets	DJ098
4	Main Jets	DJ100
4	Fuel Needles	DNO124
4	Main Air Jet Plugs	DCO500
4	Adjusting Washers	DW0001
4	Slide Springs	DSP008M
4	E-clips	DE0001
1	Plug Tool	DT001
1	Mixture Screw Tool	DT009

STAGE ONE INSTRUCTIONS

- 1. Remove the carb tops and the slide springs. Remove the slide retainers by threading one of the slide cover screws into the center of the needle retainer (Fig. A) and pull up gently. Remove stock needles and spacers, noting the order of assembly (Fig.C).
- 2. Install the Dynojet needles on groove #3 from the top. Use all stock spacers (Fig.C). Install the small Dynojet washers above the E-clip. Install the stock needle retainers with the Dynojet springs (DSP008M). After installing the slides in the carbs be sure to check slide movement manually.
- 3. Remove the carb bell mouths (Fig.D). Using the tool (DT001) provided, tap the main air jet plugs (DCO500) into place (Fig.E), open end out. Reinstall the bell mouths. *Note: The main air jet plugs must be installed for this kit to function properly.*
- 4. Remove the stock main jets and replace with Dynojet main jets provided. If you are running the stock exhaust install the DJ090 main jets. If you are running an aftermarket exhaust or slip-on with a high flowing baffle, use the DJ094 main jets.
- 5. Locate the fuel mixture tab (Fig.B). Using the tool supplied (DT009), carefully turn the tabs clockwise until lightly seated, then turn back out 2.5 turns.

