

RADIO/INTERCOM BRACKET INSTALLATION

PROVIDED HARDWARE

- (4) M4 x12 screws
- (4) #10 1 ¼" Phillips screws

TOOLS NEEDED

- Oscillating tool or Dremel with cutoff wheel
- Phillips head screwdriver
- 2.5mm Allen tool or driver bit

INSTRUCTIONS

- 1) Remove stock cup holder insert from car by using two hands to firmly pull up on the insert. The cup holder insert is held in by 4 snap tabs, one at each corner.
- 2) The cup holder placement will be positioned towards the front of the car. Cut away the two front stock tabs to allow clearance for cup holder assembly (see photo for guide).
- 3) Place the bracket into the lateral, factory guides that the stock cup holder sat into.
- 4) Connect cables to the intercom and radio using the intercom instructions. Leave slack in the cables for service accessibility.
- 5) Connect and install radio and intercom into bracket with supplied hardware.
- 6) Secure bracket to console tunnel with supplied (4) #10 screws.



V 11.13.23



562-427-8177



www.pciraceradios.com



6185 Phyllis Drive, Cypress, CA 90630

