



**KRYPTONITE**  
HARD CORE STEERING ★ SUSPENSION PRODUCTS

## **2007-2018 1500 STAGE 1 LEVELING KIT**

### **KR12STAGE1 Installation Instructions**



**CAUTION! BE SURE THE TRUCK IS IN GEAR OR IN PARK, SET PARKING BRAKE, TURN OFF ENGINE AND CHOCK TIRES!**

1. With the vehicle sitting on level ground, measure from the center of the front wheel hub to the top of the fender opening. Record this measurement;

**DRIVER SIDE;**

**PASSENGER SIDE;**

2. Using a heavy duty jack, raise up the front of the truck and place jack stands under the frame rails.
3. You will remove the wheel and tire from one side.
4. Remove brake line bracket from the upper control arm.
5. Gently pry ABS retaining clips to remove them from upper strut mounting hardware.
6. Next support the lower control arm with a jack.
7. Disconnect sway bar end links from the lower control arms.
8. Remove lower strut mounting bolts on the lower control arm.

**Continued on back**