


# KR6654 INSTALLATION INSTRUCTIONS



Rotate the steering wheel to **full lock left**. Then to **full lock right**. Counting the revolutions you will split the difference to obtain 'center'.



The master spline will engage the common spline. The remaining master splines on the sector shaft will not interfere with the standard splines.



Note the arrow is where the master splines will meet. The circled areas are showing the standard engagement one the sector shaft.

**Both 3 and 4 spline steering boxes share a common spline. In order to ensure you are engaging the correct spline, you will want to center the box prior to installation.**



See listing  
for video

**SAEJ2492 WARNING:** By installing this product, you acknowledge that the suspension of this vehicle has been modified. As a result, this vehicle may handle differently than factory-equipped vehicles. As with any vehicle, extreme care must be used to prevent loss of control or rollover during sharp turns or abrupt maneuvers. Always wear seat belts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive this vehicle safely may result in serious injury or death. Do not drive this vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your state. Consult your owner's manual, the instructions accompanying this product, and state laws before undertaking these modifications. You are responsible for the legality and safety of the vehicle you modify using these components.

**INSTALLATION ALIGNMENT NOTE:** Your vehicle may require alignment after product installation. You may incur additional costs to align the vehicle.

**INSTALLATION HEADLAMP AIM NOTE:** In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment after product installation. You may incur additional costs to adjust the headlamp system.

**INSTALLATION ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS) NOTE:** If your vehicle is equipped with active or passive safety/collision monitoring and/or assistance/avoidance systems including, but not limited to, camera- or radar/sonar-based systems, check and adjust your vehicle's systems for proper aim and function after product installation. In some instances, your vehicle may require OEM dealer service tools and factory-trained technicians to re-calibrate ADAS. You may incur additional costs to adjust ADAS systems.

 **FOLLOW US**  
@kryptoniteproducts

***KRYPTONITE*PRODUCTS<sup>®</sup>.COM**