

RAM Track Bar Installation

After Installation a Professional alignment will be required

1. Both the frame side and axle side of the track bar will be toqued to 285 ft/lbs
2. The 'K' marking on the track bar will go to the frame on the driver side.
3. Once installed snug the adjustment collar will be torqued to 80 ft lbs

Axle
285 ft/lbs

Frame
285 ft/lbs



Clamp bolts
80 ft/lbs