



KRYPTONITE

FORD SUPER DUTY WHEEL BEARING INSTALLATION

- **APPLY HIGH TEMP BEARING GREASE TO THE O-RING BEFORE INSTALLATION**
 - **SPINDLE BOLTS: 133 FT/LBS**
 - **CALIPER BOLTS: 166 FT/LBS**

CONTINUED ON BACK

- **WHEEL STUDS: 140-155 FT/LBS
(VARIES BASED ON MODEL YEAR/
WHEEL MANUFACTURER)**



 **FOLLOW US**
@kryptoniteproducts

KRYPTONITEPRODUCTS.COM