



# CAN-AM MAVERICK

## Power Adapter

Thank you for purchasing XTC Motorsports Power Adapter for License Plate Light or Whip Light.

**For more details on installation go to [www.xtcinstall.com](http://www.xtcinstall.com)**

Please read the instructions fully and familiarize yourself with the components before starting the install.



1. Unplug OEM light connector at either rear Tail Light.
2. Plug the cars harness into our adapter and then plug our adapter into the light.  
**WARNING! Keep power wire away from any hot or moving parts.**
3. Run the power wire to License Plate Light or Whip Light.
4. Crimp the red power wire to the positive wire on the light and the black wire to the negative using the supplied Heat Shrink Butt connectors.
5. Using a heat gun, heat the ends of the Butt connectors to seal them.
6. Using the supplied cable tie's, secure the power wire to the car once again making sure that the wire is kept away from any hot or moving parts.

**For more details on installation go to [www.xtcinstall.com](http://www.xtcinstall.com)** We can also be reached by email at [support@xtcpowerproducts.com](mailto:support@xtcpowerproducts.com) To purchase Accessories please visit our web site at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

**Copyright © 2023 XTC MOTORSPORTS LLC, all rights reserved.**

XTC Power Products  
A Division of XTC Motorsports LLC  
380 E Comstock Dr.  
Chandler AZ 85225  
480-558-8588  
[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)