



CAN-AM MAVERICK STOUT Stop-Tail Out Power Adapter

Thank you for purchasing XTC Motorsports Power Adapter for Rear Light Bar or Whip Lights.

For more details on installation go to www.xtcinstall.com

Please read the instructions fully and familiarize yourself with the components before starting the install.



1. Unplug OEM light connector at either Side inside the Front of the Rear Wheel Wells.
2. Plug the cars harness in between the connectors.
WARNING! Keep power wire away from any hot or moving parts.
3. Crimp the red power wire to the positive wire on the light bar, and the black wire to the negative and the Orange to Brake Light using the supplied Heat Shrink Butt connectors.
4. Using a heat gun, heat the ends of the Butt connectors to seal them.
5. Using the supplied cable tie's, secure the power wire to the car once again making sure that the wire is kept away from any hot or moving parts.

We can also be reached by email at support@xtcpowerproducts.com To purchase Accessories please visit our web site at www.xtcpowerproducts.com

Copyright © 2023 XTC MOTORSPORTS LLC, all rights reserved.

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr.
Chandler AZ 85225
480-558-8588
www.xtcpowerproducts.com