





INSTALLATION GUIDE

IE CATBACK EXHAUST SYSTEM FOR SECOND GEN VW TIGUAN

support@performancebyie.com

www.performancebyie.com



This installation guide is for instructional purposes only. For best results, professional installation by an experienced technician is always recommended. By reading this guide you agree Integrated Engineering is not responsible for any damage or personal injury caused by incorrect installation.

### DIFFICULTY



## REQUIRED PARTS

• No additional parts are required for this install

Expect 40 - 60 minutes on average

## REQUIRED TOOLS

## OPTIONAL PARTS

- 13mm Socket
- Long Flat Head Screwdriver or exhaust hanger removal tool
- 15mm Socket
- Penatrating lubricant

## BEFORE YOU BEGIN

It is highly recommended to pre-read this entire guide ahead of your installation to familiarize yourself with each step. Always park your vehicle in a safe and level location and allow plenty of time for the engine bay and exhaust to completely cool. Locate and prepare your work space with each required tool listed above. Unbox all components and verify the contents and quantities before you begin. If anything is missing or damaged, please contact us for immediate help at **support@performancebyie.com** 

#### SPECIAL NOTE:

This install guide has been photographed and written on a 2020 VW Tiguan. Some steps and factory hardware specifications may vary depending on vehicle model, year, and region. This guide is for refrence purposes only. If you are unsure of the installation procedure for any individual step or part, please seek professional help before proceeding.



## INCLUDED PARTS


- 01 AD Tiguan Resonator
- 02 Exhaust Reducer Kit w/Clamps, 76mm x 60mm
- 03 AD Tiguan Front Pipe
- 04 3" (76.2mm) OEM Style Exhaust Butt Clamp (2x)
- 05 AD Tiguan Middle Pipe
- 06 OEM Exhaust Isolator



Some items may be partially assembled.








2




Apply some penetrating spray onto the front exhaust clamp nuts/bolts. You can give the spray some time to work and come back after a few minutes. Then loosen both 13mm Nuts and push the clamp back onto the rear portion of the exhaust.













Remove both rear 13mm bolts that secure the two rear hanger. Be prepared because once these are removed, the exhuast will drop.







6



Remove the drivers side hanger from the OE exhaust to your new IE Performance Exhaust.













Assemble the reducer and install it on the front section of the IE Catback.












Raise the muffler section into place and reinstall the OEM Hanger bolt.





 Image: Description of the section is the section i






Ensure all the piping is oriented correctly and not touching anything it shouldn't be. Once everything is properly in place, ensure clamps are tightened to 40ft/lbs.









# ENJOY!

**Thank you** for purchasing an Integrated Engineering product. We are dedicated to serving your performance needs. Please check our website frequently for new product releases. If you have any questions or concerns about this product please do not hesitate to contact us.



## HOW WAS YOUR INSTALL?



Stoked?

share.performancebyie.com

## لرجا Bummed?



Sorry, let us make it right. support.performancebyie.com

801.484.2021

WWW.PERFORMANCEBYIE.COM

SUPPORT@PERFORMANCEBYIE.COM



Brother owned since 2007. Garage started for beer money.

performancebyie.com

Don't be shy. Share your project.

Ø #LiveFastBuyFun