



RUST BUSTER

RB7312R & RB7312L
Front Frame Section
1999-2006 Chevy/GMC Silverado/Sierra



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Front Frame Section

QTY

1



RUST BUSTER

RB7312R & RB7312L
Front Frame Section
1999-2006 Chevy/GMC Silverado/Sierra

1) **PREPARING YOUR VEHICLE**

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) **PREPARING YOUR WORKSTATION**

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

RB7312R & RB7312L Front Frame Section 1999-2006 Chevy/GMC Silverado/Sierra

3) PREPARING FOR YOUR INSTALL

Our part features a number of perforated plates that can be removed. If you do not wish to remove and replace the factory cab mount, remove all of the plates.



Hold the part up to the frame and mark off its coverage. Remove any lines and wires from the work area. Followed by Grinding and Cleaning the frame free of rust and debris, revealing bare metal.

4) WELD

Push the part onto the frame and c-clamp it, while using the frame holes to help with alignment.

Tac-weld the part and confirm its alignment before completely welding it onto the frame.



5) PAINT AND PROTECT

Coat the part and work area with a primer or other rust inhibitor to help prevent or reduce the risk of rust formation.

