



Make: Subaru

Model: 2011-2014 WRX STI

Application: Light Conversion

PACKAGE CONTENTS				TOOLS	
QTY		QTY			
2	Baja Designs Squadron			1/2" Socket and Wrench 9/16" Socket and Wrench Phillips Screwdriver	
2	Mounting Bracket				
4	5/16"-18 x 1" Hex Bolt				
4	5/16"-18 Hex Nut				
4	5/16" Lock Washer				
8	5/16" Flat Washer				

INSTALLATION INSTRUCTIONS



Carefully remove the side vent and fog light covers.

1



Remove the (2) Phillips screws on the inner side of the fog light.

2



Push in the (2) tabs near the location identified above and carefully pull the fog light backwards.

3



Attach the Mounting Bracket with (2) 5/16" Hex Bolts, (4) Flat Washers, (2) Lock Washers, and (2) Hex Nuts. Note that the slotted flange is on the bottom side.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Attach the Baja Design Squadrons to the Mounting Brackets. Slide the lights all the way forward and tighten the hardware.

5



Re-attach fog cover and adjust light positioning as necessary. Wire the lights and re-attach the side vent covers.

6