



1992-95 Chevrolet Corvette LT-1

Assembly and installation instructions — Please read carefully

1. The O.E. Exhaust system is completely welded from the manifold connection to the outlet spout(s).
2. To install the DynoMax Super Turbo Muffler(s), the O.E. Muffler(s) must be cut off from the assembly.
3. Cut the Muffler(s) inlet pipe 7" from the muffler end plate as measured along the pipe. See illustration. This will provide enough straight pipe length for the DynoMax Super Turbo Muffler to be clamped to the remaining pipe. A 2 $\frac{3}{4}$ " clamp is required to clamp the Muffler to the inlet pipe.
4. The outlet end plate, on the DynoMax Super Turbo Muffler(s), has a bracket that must be connected to the hanger on the vehicle. Re-use the nut off the O.E. Muffler. If a new nut is required, the thread size is metric, M10 x 1.50 Pitch.

