



Extended Length Brake Lines

Installation Instructions for Part No. 45604 – Fits all Polaris

Except Pro-X, '06 900 RMK and '06-'09 IQ chassis

PARTS INCLUDED:

Qty	Description
1	Extended Length Brake line

TOOLS REQUIRED:

7/16" & 1/2" wrenches

The PowerMadd extended length brake line is designed to completely replace your existing brake line. You will need to bleed your brake line after installation.

NOTE: The connectors on the PowerMadd brake line may appear different than your existing line. The connector with the 7/16" nut attaches to the master cylinder on the handlebar, the connector with the 1/2" nut attaches to the brake caliper under the hood.

Master Cylinder
fitting has
7/16" nut

Caliper
fitting has
1/2" nut



The extra 7/16-24 fitting is so the brake line will fit the IQ chassis. Replace the Master Cylinder fitting (7/16" nut) with the extra fitting (1/2" nut).

LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. **POWERMADD** shall not be liable for damage or injury caused by defective materials or workmanship. **POWERMADD** may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

POWERMADD®

651-462-8465

www.powermadd.com

M 45604