

RW Carbon DIY Diffuser Install Guide

Note This guide is only for parts that require bumper removal

Reccomended Tools

- 1/2 Inch Self Taping Screws
- Phillips Head Screwdriver
- Power Drill
- Trim Removal Tool
- 1/8 Inch Drill Bit



Step 1

Remove the bumper from the vehicle.

Step 2

Remove OEM Diffuser.

Step 3

Place RW Carbon Diffuser tabs, through the bumper slots



Step 4

With an extra set of hands, make sure that the diffuser is being pushed as far in as possible.

Step 5

Create pilot holes through every other diffuser tab, as close as possible to the bumper slot locations.



Step 6

After the pilot holes are made, drill a 1/2 inch screw through each hole.

Step 7

After the screws are through every other tab, secure the bumper back on to the vehicle.