

2010-19 Flex MRT Sport Touring Axle Back Part No. 91P900

Tools Required

Hack Saw or Saw All
15mm Wrench/Socket

Materials Included

Qty (1) - Left (Driver Side) Axle Back Pipe
Qty (1) - Right (Passenger Side) Axle Back Pipe
Qty (2) - 2 ¼" Exhaust Band Clamps
Instructions Sheet



Warranty Information

IMPORTANT – The warranty on this product is VOID if the product is not properly installed, or has been modified or altered in any way. If you believe that modification will be required to fit an MRT Exhaust System on your vehicle, **please contact** MRT for assistance **BEFORE** making any modifications to the system.

Instructions

1.) Place a straight edge alongside the length of stock muffler until it meets straight portion of exhaust tubing. Draw cut line, cut on line.



- 2.) Repeat step on opposite side
- 3.) Remove stock mufflers
- 4.) Remove burr or rough metal from edge of the stock exhaust tube
- 5.) Slide band clamp on to tail pipe
- 6.) Slide mufflers over existing stock tubing, insert hanger rod into isolator
- 7.) Align tip to rear fascia opening
- 8.) Position clamp to the edge of MRT exhaust so that the clamp will overlap stock exhaust tubing approximately 1/8".
- 9.) Tighten clamp while maintaining tip alignment.

NOTE: Adjustment of tip can be made by sliding the axle back in/out and rotating at clamp joint.

MRT appreciates your business; please feel free to contact us at any point with questions or concerns at 734-455-5807 or via email at Sales@MRT-Direct.com