







Plug in the sensors to the factory harness.











