




WEB LINK: http://lodoffroad.com/assets/pdfs/JRS2000 JT REAR BUMPER.pdf

VERIFY YOU HAVE ALL THE COMPONENTS BEFORE STARTING THE INSTALLATION. REFER TO THE ENGINEERING DRAWINGS AT THE END OF THIS DOCUMENT FOR A COMPLETE PARTS LIST



Be sure to read through the entire instructions before starting your installation!

Refer to the Engineering drawing included with this document for the correct hardware required at each step of the installation.

Start by removing your rear bumper. Be sure to disconnect your sensor wire harness and trailer harness before removing the bumper.

You will need to remove your trailer plug, and backup sensors from the stock bumper.

To install your trailer plug, due to the thickness of the metal on your LOD bumper you will need to bend the metal clips outward for a snug fit. Use a screwdriver to bend the metal clips.

Do this for both metal clips and test fit the trailer plug in your LOD bumper.





Once you have a snug fit double check to make sure the metal clips are "snapped" in place so the plug will not fall out. You might need to use a screwdriver to bend the clip a little more so that it snaps in.




Reverse Sensor Installation

If you do not have reverse sensors, skip these steps and install the provided plastic hole plugs.


The sensors may be installed after your LOD bumper is installed

Remove the sensor wiring harness from your stock bumper. It is helpful to label each sensor location on the harness before removing it from the bumper.

We recommend using the following MOPAR mounting brackets and bezels to mount your reverse sensors into your LOD rear bumper. You can purchase these from your local Jeep Dealership or online. You will need to order (qty 2 of each) of the four part numbers below.



Use for both the Driver Center and Driver Outside position




Sensor Mounting Bracket (Left Outer) 68341893AA



Park Distance Bezel (Left Outer) 6UD43RXFAA

Use for both the Passenger Center and Passenger Outside position



Sensor Mounting Bracket (Right Outer) 68341892AA




Park Distance Bezel (Right Outer) 6UD42RXFAA

Use a sharp utility knife or razor blade to trim off all the plastic alignment tabs from the Sensor Mounting Brackets.

Install the Sensor Mounting Bracket into the bumper as shown.


Be sure you are using the Left Outer Sensor Mounting Bracket for the Driver Side, and the Right Outer Sensor Mounting Bracket for the Passenger Side.






Install the Sensor Bezel as shown. The Sensor Bezel should snap into the Sensor Mounting Bracket from inside the bumper. Due to the thickness of the LOD bumper, if it doesn't snap in, you might need to trim the plastic spacers slightly.

Be sure you are using the Left Outer Sensor Bezel for the Driver Side, and the Right Outer Sensor Bezel for the Passenger Side.







Repeat this process for all four sensor holes making sure to use the Left Outer Sensor Mounting Bracket and Bezel for the two Driver Side Sensors, and use the Right Outer Sensor Mounting Bracket and Bezel for the two Passenger Side Sensors.



Install the four reverse sensors as shown. For best results the sensor should be rotated so the connector is orientated towards the outside of the bumper and parallel with the ground. After all of the sensors are installed, you may plug in your factory sensor wire harness.




Install the driver side and passenger side JT Rear Frame Mounts as shown using 1/2" Hex Bolts, Washers and Nuts and tighten securely.








Gently place the bumper into position as shown below resting on the hitch. Use the M10 Hex Bolt and Washers to loosely secure the bumper in place.





Install the Mount Face Plate or D-Ring Mounts as shown using the 1/2" Button Head Bolts, Washers and Nuts. Leave these bolts loose for final adjustments.





Install the Center Spacer as shown. The Center Spacer is mounted **BETWEEN** the bumper and the hitch plate. With all the bumper mounting bolts loose, the Center Spacer will slide down into position.


Install the Center Spacer from behind the bumper, between the bumper and hitch plate.



Adjust the position of the bumper so that its level with the Jeep by slightly tilting the ends of the bumper up or down. Securely tighten the two center mounting bolts.



Install your Light Bezels as shown using the 1/4" Button Head Screws and tighten securely.



Align the Mount Face Plate or D-Ring Mount so that it is straight and parallel with the bumper cutout and light bezel. Tighten Securely.



Maintenance


- Periodically check and re-tighten all fasteners.
- Periodically check your bumper for scratches or dings which can happen over time or after heavy use or highway driving. It is important to address these areas as soon as possible to prevent flaking and corrosion or rust from spreading. We recommend using Rustoleum[©] brand Black Semi-Gloss Protective Enamel (oil based). Remove loose powder coating, sand the area and clean using alcohol. Apply using a foam brush by dabbing to match the powder coat texture.







	QTY.	4	4		7	4	2	4	2	2	16	∞
	DESCRIPTION	HOLE PLUG Ø1.125"	HEX BOLT 1/2-13 X 1.50 HEX BOLT ZINC PLATE	GRS GRATE CONTRACT CO	HEX BOLL MIU-1.50 X 45mm ZING PLAIE CL8.8	BHSCS 1/4-20 X 0.50 STAINLESS STEEL	BHSCS 1/4-20 X .75 ZINC PLATE	BHSCS 1/2-13 X 2.00 STAINLESS STEEL	FLAT WASHER #12 X .56" ZINC PLATED	FLAT WASHER Ø3/8" X 1.00 ZINC PLATE	FLAT WASHER Ø7/16 X 1.25" ZINC PLATED	HEX NUT 1/2-13 ZINC PLATE GR5
HARDWARE	ITEM NO. PART NUMBER	무	8 HB5013247PGR5			10 BHSCSZ5Z0083S				14 FW3816ZP	15 FW4318ZP	16 HN5013ZPGR5
<u></u>			- 2				•					
DESCRIPTION TOTAL PLANTS WITH	IT DEAD EDANGEN WELDINGTON	JI KEAK FRAME MOUNI - US	MOUNT FACE PLATE	CENTER SPACER	FRONT LOGO GRIP TAPE							
I TAKI NOMBER	4.1 PB 2000-07	4.1 RB2000-03	2JRB2000-39	2JRB2000-30	2JRS1860-04							



























On:

