





WEB LINK: http://lodoffroad.com/assets/pdfs/JBC9640 YJ TJ LJ DESTROYER REAR BUMPER.pdf

VERIFY YOU HAVE ALL THE COMPONENTS BEFORE STARTING THE INSTALLATION. REFER TO THE ENGINEERING DRAWINGS AT THE END OF THIS DOCUMENT FOR A COMPLETE PARTS LIST



Start by removing your rear bumper. You will need to drill two mounting holes on each side in the rear cross member. This step is only needed on 1998 and newer TJ's. Earlier TJ's and YJ's already have these holes in place.


Follow the diagram shown for drilling 1/2" diamater mounting holes 7-13/16" from the outside mounting holes.



To improve your drilling accuracy it is a good idea to start small bit and get progressively larger or use a step drill. Be careful when you punch thru as to not hit the gas tank behind the cross member.

Next lower the gas tank skid plate by removing the 4 screws shown below. This will allow the skid plate to drop a few inches to gain access behind the rear cross member.







Use a floor jack or a helper to hold the rear bumper up to the rear cross member.

Install the 7/16" Hex Bolts, Nuts and Washers into the two outside mounting holes.

Start with the top bolt first. You can insert a wrench into the large rectangular hole in the bottom of the bumper to access the nut for tightening.


Tighten these securely then install the lower Hex Bolt, Nut and Washer and tighten securly.







Install the 7/16" Hex Bolts, Washers and Frame Backing Plate as shown into the holes that you drilled into the rear Cross Member. With the gas tank skid plate lowered as shown, you will be able to insert the Frame Backing Plate behind the Cross Member. You can access bolt holes thru the light bezel opening in your bumper.





Install your Destroyer Light Bezels using the 1/4" Button Head Screws provided.




Maintenance

REAR BUMPER:

- Periodically check and re-tighten all fasteners.
- Periodically check your Bumper for scratches, dings, or rust spots which can happen over time or after heavy use. It is important to address these areas as soon as possible to prevent rust and corrosion from spreading. We recommend using Rustoleum[©] brand Black Semi-Gloss Protective Enamel (oil based). Apply using a foam brush by dabbing to match the powder coat texture.











REAR BUMPER SHIPPING SHEET

Packaged by:


On:







PACKAGED SEPERATE IF BUMPER IS BARE STEEL


LOD LOGO (x1)



































HEX BOLT M12-1.75 X 40MM (2138708) (x2)

