

2015+ Dodge Challenger Rear Diffuser Installation Instructions

V2 Supplemental Sheet Only

Evans Motorsport Performance Rear Diffusers are Made in USA

Visit www.EMP.parts and go to the 2015+ Challenger EMP Rear Diffuser page to view installation video.

Perform installation at your own risk. We are not responsible for damage to vehicles or injury to persons during installation and/or use of the Rear Diffuser.

1. Attach L-brackets to large section as shown using 3/4" bolt, split lock washer and nut.
2. Insert tab on small blade piece into rectangular hole to line up with L-brackets.
3. Attach small blade piece to L-brackets using 3/4" bolt, split lock washer and nut.
4. Repeat for all 4 small blade pieces.
5. See installation video and main installation instruction sheet for instructions on attaching diffuser to car.

NOTE: Thread locker is highly recommended to keep nuts and bolts together.

The **assembly** nuts and bolts can be secured very tight even sinking the screw head into the plastic. The **4 sharp pointed installation screws** should not be overtightened, but snug and final tightening done with a hand screwdriver. The bumper plastic can strip out if these 4 screws are overtightened.



