



CAM-110008

Ford Ranger Edge/Sport 01-12 2wd Entry Level 6.0 Kit (single shock)

Suspension Components

- 1 Driver Side Upper Arm
- 1 Passenger Side Upper Arm
- 1 Driver Side Spindle
- 1 Passenger Side Spindle

Upper Arm Hardware

- 8 Upper Arm Bushings (# 2587)
- 4 7/8" OD x 9/16" ID x 2.225" Inner Pivot Sleeves (# 950029)
- 4 90 Degree Zerk Fittings (self tapping)
- 4 Grease Packets
- 2 5/8-18 x 4.5" G9 Bolts
- 4 5/8" SAE G8 Washers
- 2 5/8-18 Stover Nuts
- 4 1" x 5/8" Tall Mis-alignment Spacers (# 040031)

Spindle Hardware

- 2 1/4-28 x 2" G8 Bolts
- 2 1/4-28 x 3/4" G8 Bolts
- 8 1/4" SAE G8 Washers
- 4 1/4-28 Stover Nuts

Misc. Hardware & Components

- 1 Frame Gusset Kit (# 130006)
- 2 Bilstein 5100 front shocks (# 24-185523 | BE5-6243) w/ T-bar installed (# E4-GV3-Z009A04)
- 4 5/16-18 x 1.25" G8 Bolts
- 8 5/16" SAE G8 Washers
- 4 5/16-18 Stover Nuts
- 2 10" Limit Straps (# 030050)
- 2 Limit Strap Frame Tabs (# 040141)
- 4 1/2-13 x 1.25" G8 Bolts
- 8 1/2" SAE G8 Washers
- 4 1/2-13 Stover Nuts
- 1 Extended Front Brake Line Kit (# 130007)
- 4 8.5" Camburg Stickers

Notes:

- 1) You must press out the OEM stock spindle pin/snout and press into the Camburg spindles. Aftermarket lift spindle pins will NOT work.
- 2) We recommend running a 31-33" tire on either a 15"-17" rim with a maximum backspacing of 4.75"
- 3) Make sure ABS wheel speed sensors and tone rings are clean from debris.