

AXIAL

PRODUCT SKU: J108041

Installation Instructions for LED Tail Lights

Tools Needed:

- Flat Screw Driver
- Phillips Screw Driver
- Wire Stippers

**NOTE:

Removal of bumper is not necessary but can make the job easier.

Step 1:

Remove the 6 pins holding the splash guard onto the vehicle



Step 2:

Next, unplug the factory fog lights and loosen the (8) 19mm nuts holding the front bumper to the support beam of the vehicle.



Step 3:

To remove the fog lights, loosen the 4 phillips screws on each light.



Step 4:

Remove the unnecessary plug from the adapter harness. Then splice the red and black wires to the factory fog light harness.



Step 5:

Follow steps 1-3 in reverse.

