

INSTALLATION GUIDE

EVO X FRONT UPPER INTERCOOLER PIPE

*MAP*Performance.com

TOOLS REQUIRED:

12mm Deep Socket
10mm Deep Socket
3/8" ratchet

WHAT'S IN THE BOX:

1x MAP EVO X Front Upper Intercooler Pipe
2x 2.5" Straight Coupler
4x 2.5" T Bolt Clamps

1. REMOVE UPPER COWL COVER AND SET TO THE SIDE



2. LOOSEN CLAMPS HOLDING THE FRONT COOLER PIPE TO THE INTERCOOLER AND THE REAR UICP



3. REMOVE 2 BOLTS SECURING FRONT UPPER COOLER PIPE TO THE CORE SUPPORT



4. REMOVE FACTORY COUPLERS FROM INTERCOOLER AND REAR UPPER COOLER PIPE AND REPLACE THEM WITH THE COUPLERS INCLUDED IN KIT



5. INSTALL MAP FUICP INTO THE NEW COUPLERS, DO NOT TIGHTEN CLAMPS YET



6. INSTALL MOUNTING TAB BOLT INTO CORE SUPPORT



7. POSITION THE NEW FRONT UPPER PIPE TO YOUR DESIRED FITMENT, THEN START BY TIGHTENING THE MOUNTING TAB BOLT AND THEN TIGHTEN THE T-BOLT CLAMPS, START CAR AND CHECK FOR LEAKS.



8. REINSTALL UPPER COVER



THANK YOU FOR CHOOSING MAPERFORMANCE!

If you have any problems or concerns during installation of this product, feel free to call or email us:

1-888-MAPERFORMANCE

sales@maperformance.com

Show us some photos! [@maperformance](#) / [#maperformance](#)