

CRAWLTEK R E V O L U T I O N

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

ALUMINUM FAIRLEAD **CT10100/CT10101/CT10103**

**FOR USE WITH ALL
WINCH COMPATIBLE BUMPERS**



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2020-11-24

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

| PART # | Qty | DESCRIPTION |
|-------------------|-----|--|
| 06172/06173/06174 | 1 | CRAWLTEK ALUMINUM FAIRLEAD |
| CWLU30010 | 1 | DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5" |
| CWLU30020 | 1 | DECAL: CRAWLTEK EYES 6" X 2" |
| CWLU30030 | 1 | DECAL: CRAWLTEK JAX 3.75" X 2.8" |
| | 2 | 3/8"-16 X 1" STAINLESS STEEL BUTTON SOCKET CAP SCREW |
| | 2 | 3/8"-16 ZINC SERRATED FLANGE NUT |

TOOLS REQUIRED

SAFETY GLASSES

21MM SOCKET OR WRENCH

3/16" ALLEN HEAD SOCKET

NOTES

ALUMINUM FAIRLEAD IS INTENDED TO BE USED WITH SYNTHETIC WINCH LINE ONLY. DO NOT USE WITH STEEL CABLE, STEEL CABLE WILL DESTROY THE ALUMINUM SURFACE.

FAIRLEAD INSTALLATION

STEP 1:

REMOVE ANY EXISTING HOOK OR SHACKLE FROM WINCHLINE.

STEP 2:

REMOVE EXISTING FAIRLEAD FROM VEHICLE BY REMOVING (2) BOLTS FROM BOTH SIDES OF THE FAIRLEAD..

STEP 3:

USING THE HARDWARE SUPPLIED POSITION NEW FAIRLEAD ON TO YOUR BUMPER OR FAIRLEAD MOUNTING PLATE.

STEP 4:

REINSTALL HOOK OR SHACKLE THAT WAS REMOVED FROM FAIRLEAD.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

Be sure to show off your jeep to the rest of the CrawlTek Revolution online. Find us on facebook and instagram to keep up on new products, upcoming events and more action. Tag us @crawltek for a chance to get featured

