


CRAWLTEK R E V O L U T I O N

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

PYRO REAR BUMPER **JK20201 - MIDWIDTH** **JK20301 - FULLWIDTH**

**FOR USE WITH ALL
JK AND JKU MODELS FROM 2007-2018**



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2020-11-24

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
06050/06051	1	BUMPER - JK REAR - PYRO
06178	1	JK PYRO FRONT BUMPER NUT STRIP - YELLOW ZINC
CWLU30010	1	DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5"
CWLU30020	1	DECAL: CRAWLTEK EYES 6" X 2"
CWLU30030	1	DECAL: CRAWLTEK JAX 3.75" X 2.8"
	6	7/16"-20 X 1-1/2" GRADE 8 YELLOW ZINC HEX CAP SCREW
	8	7/16" X 0.922" YELLOW ZINC STEEL SAE FLAT WASHER

TOOLS REQUIRED

SAFETY GLASSES

18MM SOCKET OR WRENCH

10MM WRENCH OR SOCKET

11/16" SOCKET OR WRENCH

5/8" SOCKET OR WRENCH

9/16 WRENCH

7/16" SOCKET

3/16" ALLEN HEAD SOCKET



FACTORY REAR BUMPER REMOVAL

STEP 1:

REMOVE (2) 16MM BOLTS ON BOTH SIDES OF THE FRAME RAILS AND KEEP.



STEP 2:

REMOVE (2) 16MM BOLTS FROM BEHIND THE CROSS MEMBER



STEP 3:

REMOVE FACTORY REAR BUMPER FROM VEHICLE.



STEP 4:

REMOVE (3) 18MM BOLTS HOLDING THE FACTORY TOW HOOK ON (IF EQUIPPED)



ASSEMBLING THE JEEP PYRO REAR BUMPER

STEP 5:

USING THE (4) FACTORY 16MM HARDWARE TEMPORARILY INSTALL THE CRAWLTEK PYRO BUMPER, MARK ANY HOLES NEEDED TO BE DRILLED. (BOTTOM AND SIDE). REMOVE CRAWLTEK BUMPER ONCE HOLES ARE MARKED.



STEP 6:

STARTING WITH A SMALL DIAMETER PILOT HOLE DRILL OUT HOLES TO 3/4".



STEP 7:

USING THE (4) FACTORY 16MM HARDWARE INSTALL THE BUMPER LOOSELY IN PLACE.




STEP 8:

INSTALL NUT STRIPS INTO FRAME RAILS. **SEE FIGURE 7 NOTE:** LIFTING BUMPER MAY AID IN BOLT HOLE ALIGNMENT.

STEP 9:

INSTALL (6) 7/16-20" BOLTS AND WASHER THROUGH THE FRAME INTO THE NUT STRIPS. NUT STRIPS ARE SIDE SPECIFIC. **SEE FIGURE 7**





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

Be sure to show off your jeep to the rest of the CrawlTek Revolution online. Find us on facebook and instagram to keep up on new products, upcoming events and more action. Tag us @crawltek for a chance to get featured

