

CRAWLTEK

REVOLUTION

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

PYRO FRONT BUMPER SKIDPLATE

CWLJL19001

FOR USE WITH ALL
JL AND JLU MODELS FROM 18-24 & JT 20-24



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2024-12-06

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
6312	1	JL PYRO LOWER FRONT BUMPER SKID PLATE
C0060	1	BOLT PACK - JL PYRO FRONT BUMPER SKID PLATE
	4	7/16"-14 X 1-1/4" GRADE 8 YELLOW ZINC FINISH HEX CAP SCREW
	4	7/16" YELLOW ZINC FINISH STEEL SAE FLAT WASHER
	4	7/16"-14 ZINC FINISH SERRATED FLANGE NUT
CWLU30010	1	DECAL: CRAWLTEK GEARSHIFT
CWLU30020	1	DECAL: CRAWLTEK EYES
CWLU30030	1	DECAL: CRAWLTEK JAX

TOOLS REQUIRED

SAFETY GLASSES

5/8", 11/16" SOCKET OR WRENCH

TORQUE WRENCH

PRE-INSTALLATION NOTES

THIS BUMPER SKID PLATE IS DESIGNED TO BE USED WITH THE PYRO BUMPER. IT HAS NOT BEEN FITMENT TESTED FOR THE STOCK BUMPER.

JL BUMPER SKID INSTALL

STEP 1:

LOCATE THE FRAME HORNS IN THE FRONT OF THE VEHICLE.



STEP 2:

SLIDE SKID PLATE INTO PLACE ALIGNING THE 4 SKID PLATE MOUNTING BRACKETS HOLES WITH HOLES IN THE FRAME HORN.



STEP 3:

WITH THE SKID IN POSITION AND HOLES ALIGNED, INSTALL 1X 5/8" BOLT AND WASHER ON EITHER SIDE.



STEP 4:

USING AN 11/16" CLOSED END WRENCH, FEED THE SERRATED FLANGE NUT UP INTO THE FRAME HORN AND THREAD ONTO THE BOLT. LEAVE LOOSE. REPEAT ON THE OTHER SIDE. **TIP: USE SOME TAPE TO KEEP NUT FROM FALLING OUT OF WRENCH.**



STEP 5:

ADJUST ALIGNMENT OF SKID PLATE AS NEEDED, REPEAT PROCESS AND INSTALL ADDITIONAL 1X 5/8" BOLT AND WASHER AGAIN TO SECURE THE SKID PLATE TO THE FRAME. TIGHTEN ALL HARDWARE, TORQUE TO 52 FT-LBS.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

*Be sure to show off your jeep to the rest of the CrawlTek Revolution online.
Find us on facebook and instagram to keep up on new products, upcoming events and more action.
Tag us @crawltek for a chance to get featured*

