



Order Online: WWW.RENNLINE.COM
 EM Sales@rennline.com
 PH 802.655.5311
 FX 802-655-6283

Driven to improve excellence.

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

(2) Glove Box Door Stop

INSTALLATION INSTRUCTIONS FOR GLOVE BOX DOOR STOP

Fits 85-91 944, 92-95 968
 w/o Airbag



Step 1: Remove glove box door by removing the three screws on the door hinge (under dash).
 Step 2: Remove (9) screws from inside cover of glovebox door as shown in picture.

Step 3: Carefully grind or cut away remnants of factory stop arms from outside cover on both sides. It may also be necessary to trim some of the leather.



Step 4: Insert new door stop arms through inside cover as shown.

Step 5: Re-install the inside cover to the glove box door, and then the glove box door into the car.