

BBK PERFORMANCE LLC
3060 Performance Circle
Deland, FL 32724

For any questions, email us:
TECH@BBKPERFORMANCE.COM



INSTALLATION INSTRUCTIONS - INS125

THROTTLE BODIES

Part # 1767 // 2003 - 2007 Dodge Viper
Part # 1776 // 2004 - 2006 SRT 10 Truck



SPECIAL TOOLS REQUIRED: None.



INSTALL TIME: Approximately 1 hour.



DIFFICULTY: Easy.



MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: April 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 1

Disconnect the TPS and IAT sensors by pulling back on the red locking clips then squeezing the tabs while pulling the plug away from the connections.

STEP 2

VIPER ONLY



Disconnect the 2 breather hoses from the rubber intake coupler.

STEP 3

Loosen both of the clamps that hold the rubber intake coupler to the throttle body and air cleaner lid.

STEP 4

Loosen the 2 Phillips head screws that attach the air cleaner lid to its base, then carefully remove the air cleaner lid from the vehicle.

STEP 5



Disconnect the throttle cable from its tab by pulling forward on the black cable end.

STEP 6



Remove the 4 bolts that hold the throttle body to the intake manifold.

 MADE IN U.S.A. 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: April 2019



FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 7

Disconnect the vacuum hose from the bottom of the throttle body while removing it.

STEP 8



Transfer the TPS sensor from the stock throttle body to the BBK unit.

NOTE To install the TPS sensor properly, place the sensor onto the throttle body, then rotate the body of the TPS CLOCK-WISE (approximately 5°) until the bolt holes in the sensor line up with the threaded holes in the throttle body as shown in the attached photos.

STEP 9

Wipe the O-ring in the manifold off with a cloth to ensure it's clean for a proper seal.

STEP 10

Connect the vacuum hose to the bottom of the BBK throttle body and attach the BBK throttle body to the intake manifold using the supplied screws.

STEP 11

Install the rubber intake coupler over the BBK throttle body.

STEP 12

Reinstall the air cleaner lid and tighten the clamps on the rubber intake coupler.

STEP 13

Connect the breather hoses.

STEP 14

Plug the electrical connectors in to the TPS and IAT sensors.

STEP 15

Attach the throttle cable to the linkage.

VIPER ONLY

Due to production variances in the stock intake manifold, some installations may require that you slightly bend the throttle linkage arm of the BBK throttle body to assure proper alignment of the throttle cable in the groove of the linkage arm. This is easily achieved by pulling the arm into position by hand as shown in the attached photos.

MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: April 2019

