

Steeda 2005 Mustang Billet Aluminum Pedal Covers

Part # 555-1157 & 555-1158 (2 piece kit)



1. Set the parking brake.
2. Remove the rubber pads from the clutch and brake pedal.
3. Hold the Steeda pedal over the factory pedals and use them as a template to mark where the holes need to be drilled. Check the back to ensure clearance for the nuts.
4. Drill holes in the factory pedals using a 3/16" drill bit. It may be easier to start with a smaller bit for the metal pedals and then enlarge the holes.
4. Carefully place the screws through the aluminum pedals and the stock pedals.
5. Place the nuts on the back side of the pedal and tighten. Be careful not to over tighten the nuts on the gas pedal or the plastic may crack.