



STEEDA

S550 Mustang EcoBoost

Throttle Body Spacer (2015-2019)

Instructions for 555-3195



Installation

1. Remove the intake assembly. There is one screw securing the air box to the inner fender. Loosen the hose clamp securing the air box to the intake hose, and remove the hose from the box.
2. Disconnect the IAT sensor harness from the sensor.
3. Pull the box up and out of the car. There is a grommet holding it into the fender well near the screw that was removed. The box will come out of the cold air feed inlet.
4. Loosen the hose clamp on the hose coming out of the throttle body, and remove the hose from the throttle body.
5. Remove the 4 screws securing the throttle body to the intake.
6. Insert the Steeda throttle body spacer between the throttle body, and the intake, with the o-ring facing the throttle body.
7. Install and tighten the four 6mm bolts and washers, that are included in the kit. Install the washers on the throttle body side below the heads of the bolts.
8. Reinstall the components in reverse order of removal. Verify everything is tight, and enjoy!

