



STEEDA

2011+ Mustang GT (5.0L) Throttle Body Spacer

Instructions for 555-3225

Installation

1. Unbolt the engine cover and remove it for access to the throttle body.
2. Loosen the hose clamp on the hose coming off of the throttle body, and remove the hose from the throttle body.
3. Disconnect the harness connected to the throttle body.
4. Remove the 4 bolts securing the throttle body to the intake manifold.
5. Insert the Steeda throttle body spacer between the throttle body and the intake manifold with the o-ring facing the throttle body.
6. Install and tighten the four provided 6mm bolts that are included in the kit.
7. Reconnect the harness and reinstall the hose that were previously disconnected.
8. Verify everything is tight, and enjoy!

