



STEEDA®

1979-1993 FOX and 1994-2004 SN95

Mustang Front Bumper Bar

Instructions for PN#555-5095




Figure 1: Factory bumper and bumper bar attachment points

Removal of the factory front bumper bar

1. Raise the front of the car or use a lift for access under the vehicle.
2. Remove the nuts holding the front bumper to the fender using a 7/16" socket and a 1/4" drive ratchet.
NOTE: The bumper has been removed for clarity in Figure 1.
3. Using an 8mm socket and a 1/4" drive ratchet remove the bumper support brackets securing the front bumper to the radiator shroud.
4. Unplug the headlights and turn signals.
5. Using a 13mm socket and 3/8" drive ratchet, remove the bolts holding the factory bumper bar in place.
6. Slide the factory bumper bar out.

Installation of the Steeda front bumper bar

7. Line up the holes in the brackets on the Steeda front bumper bar.
8. Using a 13mm socket and 3/8" drive ratchet, reuse the factory bolts to tighten the Steeda front bumper bar in place.
9. Reinstall all of the components removed in the reverse order.