



1979-1993 FOX

Mustang Rear Bumper Bar

Instructions for PN#555-5096



Figure 1: Factory rear bumper and bumper bar attachment points

Removal of the factory rear bumper bar

1. Raise the rear of the car or use a lift for access under the vehicle.
2. Remove the nuts holding the rear bumper to the fender using a 9mm socket and a 1/4" drive ratchet.

NOTE: The bumper has been removed for clarity in Figure 1.

3. Unplug the tail lights and turn signals.
4. Using a 15mm socket and 3/8" drive ratchet, remove the bolts holding the factory bumper bar in place.
5. Remove the factory push pins holding the factory rear bumper to the rear bumper bar as shown in Figure 2.

Installation of the Steeda rear bumper bar

6. Using a 15mm socket and 3/8" drive ratchet, reuse the factory bolts to tighten the Steeda rear bumper bar in place.
7. Line up the holes on the Steeda rear bumper bar with the slotted holes on the factory rear bumper and attach together using the factory push pins removed previously.
8. Reinstall all of the components removed in the reverse order.



Figure 2: Factory rear bumper push pins



Steeda bumper bar with factory bumper brackets

For non-LX bumpers, the bumper bar will need to be modified to accommodate the factory bumper brackets. This is not necessary if you do not intend to reuse the factory bumper brackets.