



STEEEDA



2013 – 2017 Fusion Strut Tower Brace 555-5730 & 555-5732

Installation

1. Remove the two strut bolts on each side.
2. Place the Steeda strut tower brace onto the car in the orientation shown.
3. Hand start all four bolts.
4. Once all four bolts are started, tighten them to manufacturer specs.

