

Steeda Fusion Adjustable Front Swaybar Endlinks

Installation Instructions
Part #: 555-1044

Stock Front Swaybar Endlink Removal

1. Support the car on a drive on lift, two post lift, or jack stands to do this install.
2. Remove the front wheels for easier access to the necessary components.
3. Undo the nuts holding the factory swaybar endlink in place (indicated in Figure 1) by using a 6mm hex key and an 18mm box end wrench.



Figure 1: Factory front swaybar endlink

Steeda Adjustable Front Swaybar Endlink Installation

1. Set the Steeda adjustable front swaybar endlink to the same length as the factory endlink, as shown in Figure 2.
2. Tighten the jam nuts using a 3/4" box end wrench to secure the rod ends in place.
3. Install the Steeda adjustable front swaybar endlink on the vehicle and torque the provided nylon locknuts to 76 ft-lbs.
NOTE: Use 8mm box end wrench to hold the rod end stud in place.



Figure 2: Factory vs Steeda front swaybar endlinks

NOTES:

- Endlinks come pregreased from Steeda.
- Lightly grease the endlinks via the grease fitting as a part of your regular vehicle maintenance.