



STEEDA



2020+ Explorer Strut Tower Brace 555-5734

Installation

1. Remove the two strut bolts on the inside, closest to the engine on each strut tower. The two bolts closest to the firewall will be reused. Pic 1.
2. Place the Steeda strut tower brace onto the SUV in the orientation shown so you can read Steeda from the front.
3. If your Explorer didn't come with a factory strut tower brace, you might need to tap the holes. The thread size is 8mm-1.25.
4. Hand start the two factory bolts in the rear holes. Then slide the Steeda billet spacer between the brace and the top of the strut tower of the front hole on each side. Hand start the two supplied bolts and washers for the front mounting holes. Pic 2.
5. Once all four bolts are started, tighten them to the manufacturer specs. Pic 3.

