

# **INSTALLATION INSTRUCTIONS**

## **360 SERIES**





#### PRODUCTS INCLUDE:

- (2) RIGID 360 Lights (4 or 6 inch)
- Mounting hardware


#### **IMPORTANT**

THANK YOU FOR PURCHASING RIGID INDUSTRIES' PRODUCTS FOR YOUR VEHICLE.

Please read through all of these Instructions and tips before proceeding with the installation. We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems.

#### **WIRING LEADS**



RED WIRE = PROJECTING TRIGGER

BLACK WIRE = GROUND

WHITE WIRE = BACK-LIGHTING TRIGGER



## **FIGURE 1** INSTALLATION INSTRUCTIONS


### 4" 360-SERIES ASSEMBLY DIAGRAM

Α	M8x25mm Carriage Bolt	Place through bracket
В	M8 Flat Washer	Place on carriage bolt
С	M8 Lock Washer	Place on carriage bolt
D	M8 Nut	Tighten light to bracket
Е	M6 Ny Lock Nut	Place in Heatsink
F	Mounting Bushing	Slide into Heatsink
G	6-32x.375" Socket Head	Tighten mount bushing to Heatsink
Н	M6 Flat Washer	Place on item I prior to install
I	M6x22mm Socket Head	Tighten the bracket to the light (Torque 32in-lbs)



### **6" 360-SERIES ASSEMBLY DIAGRAM**

Α	M8x25mm Carriage Bolt	Place through bracket
В	M8 Flat Washer	Place on carriage bolt
С	M8 Lock Washer	Place on carriage bolt
D	M8 Nut	Tighten light to bracket
Е	M6 Ny Lock Nut	Place in Heatsink
F	M4 Ny Lock Nut	Place into mounting bushing
G	Mounting Bushing	Slide into Heatsink
Н	M6 Flat Washer	Place on J prior to install
ı	M4 Flat Washer	Place on K prior to install
J	M6x22mm Socket Head	Tighten bracket to the light (Torque 32in-lbs)
К	M4x22m Socket Head	Tighten the bracket to the light (Torque 9in-lbs)



Your installation is now complete. Welcome to the Rigid Nation!

#### WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty 779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337