

COIL OVER PLUG KIT

Polaris RZR Installation Guide

PARTS LIST



2 IGNITION COILS

1 WIRING HARNESS

1 ROUTING CLIP

1 BOLT

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION



96060001



INSTALLATION

Remove engine access panel at the bottom of the cargo bed.

Remove the stock spark plug wires.

Remove the stock ignition coil.



STOCK COIL AND PLUG WIRES

Push the new Dynojet ignition coils securely over the spark plugs.

Plug the Dynojet wiring harness into the stock ignition coil connector. Plug the Dynojet ignition coil connector with the GREEN wire into the LEFT coil. Plug the one with the BLUE wire into the RIGHT coil.

Secure the wires to the frame with the supplied clip.

Secure the stock ground wire with the ring terminal to the frame using the supplied bolt. (Re-use the stock nut.)

Reinstall the engine access panel.



DYNOJET COILS AND WIRING HARNESS



PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM

© 2019 DYNOJET RESEARCH ALL RIGHTS RESERVED