

ICOM F5021 QUICK REFERENCE GUIDE



^ - Channel UP
v - Channel DOWN
Blue  - Power

P0 - Squelch

Press and hold until “SQ” appears. Use the up and down arrows to adjust. Hold P0 to save.

P1 - Channel 1

Press to go to the first channel of the selected zone.

P2 - Home Channel

Press to go to Channel 2 Zone 1 “PCI RLY”.

P3 - Zone

Press to display the zone you are on. Use the up and down arrows to scroll through the available zones. Press P3 to select that zone.



562-427-8177



www.pciraceradios.com



6185 Phyllis Drive, Cypress, CA 90630

