





## Pin colors used for PCI RaceAir wiring harness Part #5814

**PIN 8/White:** Run jumper to Pin 3 so LED is lit when switch is turned ON.

PIN 2/Red: 12V Positive IN from Battery.

PIN 3/White: 12V OUT to Device's Positive.



## PIN 7/Black & Green:

Device and Battery ground.

**NOTE:** RACEAIR BOOST IS POLARITY SENSITIVE. IF YOU REVERSE, YOU WILL DAMAGE UNIT.

(Red Positive+ Black Negative-)

Standard Raceair motors with 2 black wires are not polarity sensitive, use one black wire for ground and the other to power motor.

FOR ADDITIONAL HELP, PLEASE CALL US AT: (800) 869-5636 • WWW.PCIRACERADIOS.COM