

## CF105UB

MARICE &
ATV/UTV
ID" MARICE
SUBWOOFER
WITH
RGB LIGHT



MODEL	TYPE	RMS/PEAK POWER
CF10	10" SUBWOOFER	300W/600W

### **CF10 Features**

Marine/UTV 10" Subwoofer Speaker

Continous Power Handling 300W RMS

Peak Music Power 600W MAX

IP65 Marine Grade Compliant Specifications, 100% UV Stable

Integrated RGB LED Lighting

High Temp injection Molded Composite High Gloss Basket With UV Coating

High Temp injection Molded Composite Grilles Black Carbon Fiber Texture

with 316 Metal Mesh

Motor Structure Use Y35 Ferrite Main Magnet

Sensitivity: 88dB at 1W/1M Nominal Impedance: 4-Ohm


Injection Molded, UV-Compliant, Polypropylene Cone, Butyl Surround

RF Remote LED Controller Or WIFI Controller Option Available For

Multi-Function RGB LED Lighting (Optional)

#### **PACKING INCLUDE**

One Peices Marine/UTV Grade Subwoofer Speaker
1X1.5M #18 Speaker Input Wires With Fast Terminal
1X1.5M #22 RGB LED Power Input Wires With Fast Terminal
6XM5.2 Philips Inner Hex Head 304 Stailess Screw(4mm Hex Tool)
Owners Manual



MODEL	CF10
Nominal Diameter	<b>10</b> " (254)
Туре	_
Nominal Impedance ( Ohms )	4Ω
Frequency Response ( Hz )	25-2 kHz
Voice Coil Diameter	2" (50.0mm)
Power Handling RMS/PEAK	300 <b>w</b> /600 <b>w</b>
Fs-Free Air Resonance (Hz)	40
Qts	0.62
Vas - cu.ft (Liter)	1.042 (29.5)
Sensitivity(1W/1M)	88dB
Xmax	0.5" (13mm)
Mounting Hole	7.87" (200mm)
Mounting Depth	5.02" (127.5mm)

We Reserve The Right To Change Products And Specificatins At Any Time Without Notice. Images May Or May Not Include Optional Equipment

#### Installation Considerations before attempting Install,


- 1. Be sure to carefully read and understand the instructions before attempting to install these speakers.
- 2. For safety, disconnect the negative battery terminal from the battery prior to beginning the installation.
- 3. For easier assembly, we suggest you run all wires prior to mouinting speakers in place
- 4. Use high quality connectors for a reliable installation and to minimize signal or power loss.
- 5. Think before you drill! Be careful not to cut or drill into gas tanks, fuel lines, brake or hydraulic lines, vacuum lines or electrical wiring when w orking on any vehicle. If installation in a boat, take care not to cut or drill through the main hull.
- 6. Never run wires underneath the vehicle. Running the wires inside the vehicle or hull area provides the best protection.
- 7. Avoid running wires over or through sharp edges. Use rubber or plastic grommets to protect any wires routed through metal, especially the firewall.


#### Mounting

- 1. Determine where the speakers will be mounted. Ensure an area large enough for the speaker to mount evenly. Be sure that the mounting location is deep enough for the speaker to fit; only mount to a flat surface. Use extra caution when mounting on panels with ureathane foam.
- 2. Refer to the specification chart to determine the proper diameter hole to cut for your speaker model.
- 3. Mark the locations for the mounting screws. Drill the holes with a 0.157" bit.
- 4. Feed the speaker wires through the cutout and connect to the speaker terminals. Be sure to observe proper polarity when connecting the wires. The speaker's positive terminal is indicated with a "+".
- 5. Fit the speaker and mount into place using six (6) screws.
- 6. Tighten the screws until the speaker is snug in place
- 7. LED CONNECTIONS: There are two options to choose from:
- 7-1, Connect RGB Wires To RF RGB LED Controller Or WIFI RGB LED Controller (Optional)
- 7-2, Connect To Battery (DC12V), Speaker RGB LED Fast Terminal "V+" Connect To Battery Positive.
  - 1) Green Color: "G" Fast Terminal Connect to Battery Negative
  - 2) Red Color: "R" Fast Terminal Connect to Battery Negative
  - 3) Blue Color: "B" Fast Terminal Connect to Battery Negative
  - 4) Purple Color: "R" And "B" Fast Terminal Connect to Battery Negative
  - 5) Yellow Color: "R" And "G" Fast Terminal Connect to Battery Negative
  - 6) Cyan Color: "B" And "G" Fast Terminal Connect to Battery Negative
  - 7) While Color: "R" And "B" And "G" Fast Terminal Connect to Battery Negative

# **△**▲FOR ALL ELEMENTS

#### 







FOR MORE INFORMATION PLEASE VISIT

WWW.DS18.COM

