



Please ensure you securely tighten the top of your valve before installation.



Failure to do so could result in loss of performance or damage to product

Please note: If there is a spare spring(s) included in this kit it is intended for use inside the valve when the ECU has been remapped.