



Brey-Krause Mfg. Company
1209 West Lehigh Street
Bethlehem, PA 18018
Phone: 610-867-1401
Fax: 610-866-1433

R-9511 Mazda Miata Fire Extinguisher Mount Instructions

Step One:

Make sure ignition is off and key is removed.

Step Two:

Slide the seat completely back.

Step Three:

Remove front mounting bolts.

Step Four:

Slide seat all the way front.

Step Five:

Remove rear-mounting bolts.

Step Six:

Place seat upright on bench.

Step Seven:

Remove front seat mounting bolts.
(See Figure 1.0)

Step Eight:

Slide fire extinguisher bolt tabs between seat and rail.

Step Nine:

Replace bolts.

Step Ten:

Remount seat back into car. Slide the seat all the way forward and back to check for clearance. Adjust if necessary. (See Figure 1.1)



Figure 1.0 - Front Mounting Bolts



Figure 1.1 - Fire Extinguisher Mount Installed