



### STEP 1 – PRIOR TO INSTALLATION

- A) Bushwacker only approves installing the flares according to these written instructions with the hardware provided. WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D) Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E) Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F) Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint **BEFORE** installing flares. Spray inner fender wells with undercoating **AFTER** flare attachments have been completed.
- G) Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.
- H) Care & Cleaning:** Bushwacker fender flares are built to last; any detergent you use to wash your vehicle is sufficient to clean the flare. Do not use any harsh abrasive detergents.

# Nissan Pocket Style® Fender Flares Set of 4

Set Part #70908-02

Rev-8 03/01/2016

For complete fitment info visit : [www.bushwacker.com](http://www.bushwacker.com)

### TOOLS FOR EASY INSTALLATION:

- Utility Knife
- Vinyl or Plastic Putty Knife
- Automotive Trim Pry Tool
- #2 Right Angle Ratcheting Screwdriver
- Socket Wrench
- 1/2" Socket

**PLEASE READ:** Dirt and debris can become lodged between the fender flares and the vehicle's fenders, causing scratching and paint wear from vibration. Lund International is not responsible for any damage, and the installation of our fender flares is done with the buyer's understanding that this scratching and paint wear may occur.

### LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS


- To claim a warranty, you must provide Proof of Purchase.

## Included in Hardware Kit:

- |    |   |    |   |    |   |    |   |    |  |    |   |    |   |
|----|---|----|---|----|---|----|---|----|--|----|---|----|---|
| 1. |  | 2. |  | 3. |  | 4. |  | 5. |  | 6. |  | 7. |  |
|    | CL1-0005,<br>Dacromet "S"<br>Spring Clip,<br>14 pcs                                 |    | SW1-0050,<br>10 x 5/16 Phillips<br>Truss Screw,<br>14 pcs                           |    | SW1-0067,<br>5/16 x 18 x 3/8"<br>SS Torx Screw,<br>35 pcs                           |    | NU1-0019,<br>5/16-18 Jam Fin.<br>Nylock Nut,<br>35 pcs                              |    | WA1-0012,<br>.320 x .700 x .03<br>SS Washer,<br>35 pcs                               |    | SW1-0052,<br>T-45 Torx Bit,<br>1 pc   |    | ET1-0002,<br>Edge Trim Tool,<br>1 pc  |
| 8. |   |    |   |    |   |    |   |    |  |    |   |    |   |
|    | GP1-0022,<br>Small Wiper Style<br>Edge Trim,<br>316 inches                          |    |   |    |   |    |   |    |  |    |   |    |   |

## STEP 2 - EDGE TRIM INSTALLATION

- A) Peel two to three inches of red vinyl backing away from Edge Trim (GP1-0022) tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).
- B) Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.



## Pocket Hardware Installation:



Put a Washer (WA1-0012) on each Bolt (SW1-0067).




Put each Bolt/Washer combination through a pocket hole in the flare, Bolt head and Washer on the outside.




Place a Nut (NU1-0019) over the end of each Bolt and tighten, using a 1/2" wrench for the Nut and the supplied Torx Bit (SW1-0052) for the Bolt. Repeat for remaining pockets.


# Front Flare Installation Procedures (Driver's Side):




Remove factory mud flaps if installed, and one extra unpainted screw above mud flap. Also remove screw located at front of fender just above bumper. If no mud flaps were removed, remove two unpainted factory screws per side. *Save for reinstallation.*




Position flare on fender. Line up the two lowest holes in flare with the factory holes and start the two factory screws. Line up the forwardmost hole in flare with the hole just above the bumper and start one factory screw. *Do not fully tighten screws.*



Install two Clips (CL1-0005) over fender lip, lining up the hole in clips with the holes in flare. Start Screws (SW1-0050) in each Clip. *Do not fully tighten screws.*




Insuring the flare is properly located on fender, apply moderate pressure to outside surface of flare, and tighten screws, beginning with the two rearward factory screws working toward the front of the fender flare.



Completed front flare installation.


# Rear Flare Installation Procedures (Driver's Side):




Remove factory mud flaps if installed, and one extra unpainted screw above mud flap. *Save for reinstallation.*



Hold flare in position on fender with moderate pressure. Line up the lowest hole in fender with the hole in flare and start the factory screw. *Do not fully tighten screws.*



Install five Clips (CL1-0005) over fender lip, lining up the hole in Clips with the holes in flare. Start Screws (SW1-0050) in each Clip. *Do not fully tighten screws.*




Insuring the flare is properly located on fender, apply moderate pressure to outside surface of flare, tighten all screws, beginning with the factory screw working toward the front of the fender flare.



Completed rear flare installation.

## Edge Trim Tool Procedures:



Using supplied Edge Trim Tool (ET1-0002), seat edge trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



Using flat end of supplied Edge Trim Tool (ET1-0002), seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.